


# Directions for Removing / Reattaching Skirt Door Panel



## Directions for Removing Skirt Door Panel

1. Remove snap caps using a small plastic putty knife or something that will not scratch the surface. Slide the putty underneath the cap and pop out/off
2. Unscrew the philips screws until skirt door panel is released. Snap cap washer will come off with screw.

## Directions for Reattaching Skirt Door

1. Place door panel back in frame . **CHECK** for proper alignment
2. Place snap cap washer on screw and place in hole on door . Tighten screw down snug. **DO NOT** over tighten.
3. Snap the snap caps back into place,

